



CROWN IMPERIAL ASSEMBLY INSTRUCTIONS

Glass Wall Unit



Glass Wall Unit Parts

Parts Supplied



A



D



B



E



F



C


























G



Part Letter	Part Name	Quantity
A	End Panel	2
B	Glass Shelf	2
C	Top/Bottom Panel	2
D	Back Panel	1
E	Transformer for Light	1
F	Low Voltage Aluminium Light	1
G	Hanging Bracket	1 pair



<p>A</p> 	<p>B</p> 	<p>C</p> 	<p>D</p> 	<p>E</p> 
<p>F</p> 	<p>G</p> 	<p>H</p> 	<p>J</p> 	<p>K</p> 
<p>L</p> 	<p>M</p> 	<p>N</p> 	<p>P</p> 	<p>Q</p> 
<p>R</p> 	<p>S</p> 	<p>T</p> 	<p>U</p> 	
<p>V</p> 	<p>Y</p> 	<p>Z</p> 		
<p>W</p> 				



Fitting Letter	Fitting Name	Quantity
A	Metal Dowel	8
B	Metal Cam	8
C	Wooden Dowel 8 x 40mm	8
D	Wooden Dowel 5 x 25mm	
E	Connecting Screws (M/F)	2 pairs
F	Black Chipboard Screw 8 x 45mm	
G	Countersunk Screw 8 x 1 1/4"	
H	Countersunk Screw 6 x 5/8"	
J	Countersunk Screw 6 x 1/2"	
K	Flange Head Screw 6 x 3/4"	4
L	Flange Head Screw 6 x 5/8"	
M	Euro Screw 6 x 11mm	
N	Round Head Screw 6 x 5/8"	
P	Shelf Stud	8
Q	Rubber Sleeved Shelf Stud	
R	Angle Bracket	
S	Door Buffer Pad	2
T	5mm Plugs	20
U	35mm Bung	2
V	Crown Conceal Cap	
W	Hanging Plate	2
Y	Peg-o-Lock	
Z	Plinth Clip	

Assembly Instructions

Step 1. Insert fittings into End Panels


Insert Metal Dowels (fitting A) and Wooden Dowels (fitting C) into the end panel, as shown.

Mirror this for the remaining end panel.

1.1. Insert fittings A and C



1.2. Position of fitting B in End Panels




Step 2. Top/Bottom Panel

Insert the Circular Cams (fitting B) into the holes in the top panel.


Ensure the arrows on the circular cams, are pointing outwards, towards the pre-drilled edge.

Repeat for the bottom panel.

2.1. Insert fitting B



2.2. Position of fitting B in Top/Bottom Panel



Step 3. Fit Top and Bottom Panels

Step 3.1

Take the top panel and push firmly home onto the end panel, as shown.

Ensure the cams are facing outwards.

3.1. Fit Top Panel to End Panel




Step 3.2

Using a screwdriver, turn the circular cam clockwise to lock.

Repeat for all cams.


3.2. Lock Cams to secure



Step 3.3

Repeat the above, to fit the bottom panel.


3.3. Repeat to fit Bottom Panel



Step 4. Fit Back Panel

Slide the back panel into the grooves in the top and bottom panels, and push home into the end panel.

4. Fit Back Panel



Step 5. Fit remaining End Panel

Take the remaining end panel and push firmly home, as shown.

Ensure all cams are locked.

5.1. Fit remaining End Panel



Step 6. Fitting Hanging Brackets

Step 6.1

Push the hanging bracket into the pre-drilled holes, located on the back of the end panel, as shown.

6.1. Insert hanging bracket



Step 6.2

Secure the hanging bracket, using two screws (fitting M), fixing into the top panel through the pre-drilled holes located at the top of the hanging bracket.

6.2. Fix hanging bracket



Step 6.3

Repeat this, to attach each hanging bracket to the unit.

6.3. Back View with Hanging Brackets




* NOTE: The back panel is only partially drilled, to reveal hanging bracket adjustment mechanism. If so required, complete 35mm diameter hole.

Step 6.4 Adjustment Mechanism

Now look inside the cabinet. Located in the holes found in the back panel are two adjustment mechanisms.

- Upper hanging bracket screw for height adjustment,
- Lower screw for pulling the cabinet tight into the wall.

6.4.



Step 7. Shelving

NOTE: Shelving is optional.

When the cabinet is installed, position shelves accordingly. Using four shelf studs (fitting N) position the shelf at the height desired.

Repeat this, if extra shelving is required.



Complete Glass Wall Unit

