



600 'L' CORNER WALL UNIT

1. Insert fittings into End Panel as shown. Mirror for the other End Panel.




2. Insert the circular cams B into the holes in the bottom panel, ensuring that the arrows point towards the drilled edge. Push the panel firmly home onto the end panel. Using a screwdriver, turn the cam clockwise to lock.




Repeat for the top panel.


3. Push the back panel into the groove on the end panel. Secure using six K screws.




4. Push the remaining end panel firmly home onto the top and bottom panels. Lock the cams as before.



5. Push the remaining thin back panel into the groove on the end panel. Secure using six K screws.




6. Slide the thicker back panel between the two thin back panels, as shown. Secure using four F screws. Once in place, tighten the two remaining K screws from step 5.




* NOTE: Do not tighten the two screws marked K*, until step 6. This will make it easier to fit the thicker back panel.


7. Knock the two hanging brackets into the holes as shown. Fix with two K screws per bracket into the end panel.



9. Fix the hanging plates W at the heights as shown. The dimensions given are from the top of the worktop (assuming 40mm thick worktop) to the underneath edge of the hanging plate.



8. Viewed from the inside of the cabinet, use the upper hanging bracket screw for height adjustment, and the lower screw for pulling the cabinet tight into the wall.



10. Fit any loose shelves, as required.

FITTINGS SUPPLIED					
A		Metal Dowel	8	P	Shelf Stud 10
B		Metal Cam	8	S	Door Buffer Pad 2 pairs
C		Wooden Dowel 8 x 40mm	8	T	5mm Bung 10
E		Connecting Screws (M/F)	2 pairs	U	35mm Bung 2
F		Black Chipboard Screw 8 x 45mm	4	W	Hanging Plate 2
J		Countersunk Screw 6 x 1/2"	4	Y	Peg-o-Lock 1
K		Flange Head Screw 6 x 3/4"	16		